

HEAVY DUTY GREASE AND GRIME REMOVER

Heavy Duty Grease and Grime Remover is a powerful degreasing cleaner developed to remove burnt-on grease, stubborn grime, and oily residues from kitchen surfaces and cooking equipment. It is specially formulated for demanding cleaning tasks on ovens, air fryers, stovetops, grills, range hoods, pans, and similar washable surfaces exposed to heavy grease accumulation. The product penetrates greasy buildup quickly and helps restore surface cleanliness, hygiene, and shine within a short contact time. Its spray form supports easy application and makes routine kitchen cleaning faster and more practical.

Intended Use

The product is intended for the removal of heavy grease, burnt residues, and kitchen grime from hard washable cooking surfaces and equipment. It is suitable for routine and intensive cleaning applications in domestic and professional kitchens where strong degreasing performance is required. It is designed for use on surfaces affected by cooking oils, baked-on food residues, and stubborn greasy deposits.

Application Areas

The product may be used inside ovens and on oven racks, air fryer baskets and trays, stovetop burners and cooking surfaces, range hood inner and outer panels, pan and pot bottoms, cooker hood filters, grills, and similar kitchen equipment. It is suitable for washable metal and heat-resistant kitchen surfaces requiring deep degreasing and grime removal.

Product Advantages

The product provides strong degreasing action and helps remove burnt and stuck-on grease residues with minimal effort. Its spray nozzle allows direct and even application to the soiled area, improving ease of use. It acts quickly within 2–3 minutes under normal conditions and helps reduce the need for prolonged scrubbing. After cleaning, it supports a clean and revived surface appearance without visible dullness when used correctly.

Directions for Use

Shake well before use. Make sure the surface is cool before application. Spray the product evenly onto the greasy or dirty surface. Allow it to act for 2–3 minutes depending on the level of contamination. Scrub with a

FOR MORE INFORMATION, PLEASE CONSULT THE MATERIAL SAFETY DATA SHEET



HEAVY DUTY GREASE AND GRIME REMOVER

soft sponge or cloth, then rinse thoroughly with water. Repeat the application if necessary for heavy buildup. Test on a small inconspicuous area before first use on sensitive surfaces or specialty finishes.

Physical and Chemical Properties

Appearance: Clear liquid

Odor: Characteristic

Form: Liquid

Application Type: Spray degreaser

Action Time: Approx. 2–3 minutes under normal use conditions

Foaming Level: Controlled

Residue After Use: None when rinsed as directed

Surface Effect: Clean and shiny finish

Packing

Available in a range of packaging options from 500 ml up to 20 L, depending on customer preference, product type, and filling requirements.

Storage Conditions

Store in the original, tightly closed container in a cool, dry, and well-ventilated place. Recommended storage temperature is 5–30°C. Protect from direct sunlight, frost, and excessive heat.

Safety Information

Use the product only as directed. Avoid contact with eyes and prolonged skin contact. Do not mix with other cleaning chemicals unless compatibility has been confirmed. Keep out of reach of children. Refer to the Safety Data Sheet (SDS) for detailed information on safe handling, storage, first aid measures, and disposal.

General Information

The information provided in this Technical Data Sheet is based on current knowledge and practical experience. It is intended as a general guideline for product application, handling, and storage, and does not constitute a guarantee of performance under all conditions of use.

FOR MORE INFORMATION, PLEASE CONSULT THE MATERIAL SAFETY DATA SHEET

